




<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0101	00172694		Cable harness
0102	00172696	00423704	Cable harness
0103	00183210	00423702	Cable harness
0104	00172695	00423701	Cable harness
0111	00172697		Coupling
0113	00172699		Knob-programme
0116	00266748	00267678	Tray handle-dispenser
0120	00552829		Part not included in this appliance
0125	00484134		Control module
0135	00267087	12004729	Power cord
0136	00171254	00623842	Capacitor-interference suppre.



<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0201	00095209		Holder
0202	00182194		Lid
0204	00186869	00429205	Transit bolt
0205	00186870		Transit bolt
0206	00416875		Auxiliary tool
0207	00080451	00493529	Floor Securing Component
0208	00040302		Foot
0212	00362761		Case-rear part
0213	00218343		Worktop
0214	00167581		Holder
0215	00358923		Rail
0216	00358931	00435791	Rail
0218	00182154		Electric lock
0219	00167587	00067083	Holder
0220	00216550	00235567	Front panel
0223	00171264		Bushing
0224	00171269		Hinge-window
0225	00439671		fastening ring
0230	00354127	00715042	Ring
0231	00354128	11020392	Window
0232	00366232		Frame-window
0233	00266751		Handle
0234	00171255		Axis
0235	00173251	00634207	Latch



<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0301	00142369	00145563	Motor
0302	00154740		Carbon-brush
0303	00168798		Holder
0304	00171272		Fixture
0305	00171271		Screw
0307	00170961		Sensor-NTC
0308	00171273		Holder
0309	00265961		Heating element
0310	00433761	00448032	Shock absorber
0311	00354131	00678914	Belt-drive
0312	00171270		Screw
0313	00354130	11002942	Pulley
0314	00172686		Bearing set
0315	00483764		Sealing
0316	00236013		Tub
0317	00171291	00613082	Shaft seal
0318	00215113	00773699	Drum
0319	00238441	00715100	Tub
0320	00214721	00773470	Weight
0321	00265965		Band
0322	00354135		Boot gasket
0323	00354134		fastening ring
0324	00214720		Weight
0325	00182243	00631639	Fixing kit
0326	00171275	00606818	Spring-tank
0327	00289822		Support



<b>Position ID</b>	<b>Spare part no.</b>	<b>Replacement</b>	<b>Description</b>
0401	00354123		Dispenser tray
0402	00354122		Dispenser tray-lower part
0403	00265957		Dispenser tray-upper part
0404	00171267		Holder
0405	00428210		Valve-magnet
0406	00171262		Hose-valve/soap box
0407	00027780		Filter-water inlet
0408	00353924	00700836	Hose-inlet
0411	00172394	00421488	fastening ring
0412	00265958		Hose-fill
0413	00172395	00603523	fastening ring
0414	00171263		Ball-sump
0415	00480436		Eco-hose-sump
0416	00173229	00608010	Drain hose
0417	00424981		Pressure chamber
0418	00171265	00491919	Hose-pressure chamber
0419	00427040		Regulator-water level
0420	00358305		Hose
0421	00358304		Container return
0422	00358306		Outlet hose
0423	00181184		Hose-vent
0424	00084713	00655300	Holder
0435	00142370	00145787	Pump-drain
0436	00182430		Filter-fluff